3D HOLOGRAPHIC LED DISPLAY OF IMAGES & VIDEO

INSTRUCTION MANUAL



SIMPHIX SIM-50-WF & WFC Marketing & Distribution Agent



Do not disassemble the device cf insert TF card without permission!

QUICK GUIDE

1. This is a WiFi Model and does NOT require the internet.

2. The Software for PC, IOS, and Android Mobiles may be downloaded from the link provided or directly from our website (www.simphix.com)

3. After downloading the software connect the device to your PC/MObile.

a) Switch on the WiFi in your PC/phone, and you will see the device.

b) Click on the device , and enter the given password to connect.

4. Once you are connected, you can add/delete your content from your PC/ Mobile as per your convenience.

5. When adding content, please note that there should be no space in the file name or file path

eg. CORRECT - c:\desktop\simphix_content\myfirstcontent.mp4

eg. INCORRECT - c:\desktop\simphix content\my first content.mp4 6. There is a button at the back of the device. This is to change modes between Aux (Blue) and WiFi (Red). Keep it in WiFi Mode.

7. Aux mode is needed when you require to use the remote controller or want to set up multi unit devices. Long-press back button to change modes.

Please note that any tampering with the device will lead to Warranty being Nul N Void. Also, if you have opted for the SIMphix Maintenance, we take no responsibility if the Card has been disassembled and/or when the device has been opened. Maintenance is valid for all manufacturing defects only.

List	
Goods	Quantity
Holographic Intelligent Display Dsee-50z/Dsee-50	1
Power adapter	1
Remote control	1
Wall-hung fixing parts	1
Wall-hung expansion screws	2
Wall-hung fixed gasket	6
Warranty Card	1
Certificate	1
User manual	1

Holographic intelligent screen Dsee-50z / Dsee-50 is one display device which use of human visual persistence (POV) technology, rotating imaging through one belt of ultra-high-density LED light, then presenting 3D visual effects. This device has the character of ultra-low power consumption, ultra-high attractiveness, easy to carrying and high cost performance etc.



Description of back interface



- Indicator light: Indicate the power, ON/OFF, Mode-switching and so on.
- 2 Setting button: Switching Mode, Pairing remote control .
- 3 Slave interface: Used in slave mode (See "Slave mode")
- 4 Power interface: Plug in the power adapter.



- ON: Run the device, switch stand-by status to operating status
- 2 OFF: Stop the device, switch operating status to stand-by status
- 3 Previous: Switch the playing screen to previous one
- 4 Next:Switch the playing screen to next one
- 5 Renew: Start display the first file
- 6 htness control: This version isn't available.

Connect power:

connect power adapter to the power interface of devcie, power on, the front side can see the lamp bead slowly light up and out, the backside indicator is red.



Match remote:

when device is in stand-by status, push the setting button on the backside, indicator light turns red to blue, point remote control to device and long press 100% button in brightness control area, blue light flashes and turns red, pairing successful.

ON/OFF:

3

Point remote control to device, press "Run", device starts to rotate and image turns up, the back indicator turns red and opens successfully.

Point remote control to the running device, press "Stop", the internal rotation of device turns slow to stop, the back indicator turns red, close successful.

Operation

Δ

5

Switch display content: point remote control to devcie, press ">>", switch to next file and display it Point remote control to device, press "<<", switch to previous file and display it.

Mode switch

Device can switch between two modes, host mode and slave mode. The host mode displays the content as a single machine. Device in slave mode needs to be connected with that of the host mode so that all the areas can show the content. The default device is the host mode. Device of the slave mode neither can display content individually, nor can control it with remote control.

1.Switch mode

When the device is standby, use the sharp object to hold down the setting key on the back, the indicator light is on by the red light, it means that the mode is switched to the host mode. The indicator light is on by the blue light, it means that the mode is switched to the slave mode.

2.Device connection

When you want to display one video or picture by several devices, the way to connection is Below:

Slave socket 2 of device 1(set to host mode) is connected to slave socket 1 of device 2(set to slave mode), slave socket 2 of device 2 is connected to slave socket 1 of device 3(set to slave mode), and like this setting, you just need one fan set to host mode for control.



Play settings

6

It needs to be connected with wifi, then using PC software to do play content settings, play mode settings, and play order. Plz follow DSEELABTM-Hologram LED FAN-User manual to install PC software.

Installation instructions



Dsee-50/Dsee-50z can be installed on the wall and bracket. This installation is just about being installed on the wall, if you need to be installed on the bracket, plz consult with distributors.



Wall-hung fixing parts

You need expansion screws or common screws to fix the wall-hung fixing parts on the wall directly. Pay attention to that you you need to using about three gaskets between wall and wall-hung fixing parts, leaving 5mm space to help fixing the device.



POV CONSOLE



Operation

Download Software from: Website www.simphix.com

Google Drive

https://drive.google.com/drive/folders/1CGqxdSH-LCPcR9qis0W0du7WzeDFovmh?usp=sharing

The device is not connected, please check the network
Model: Select the model
Connect the device
(Inquire malfunction)

Install software

Download the software package, unzip file "PC_Dseelab+version No.zip", double click "POV.exe" to run the schedule manager, and it will prompt you to check network connection.

DSECLAB	The device is not connected, please check the network	
off on The device is not connected SD card remaining capacity: 46	Model: dsee-50z 💌	
Connect the device	Connect the device	
Screen brightness	Inquire malfunction	
Timing		
000		

Connect the device

Δ

PC connected to device WiFi, Select the device model to connect the device, if it reveals connect failed, click the button of inquire malfunction to check the error.



	DSEE.LAB							
				Edit Add Up Down Empty				
			F	ile Name	Size	Cycles	Operation	
		(off	on		xxx.mp4	1.1M	1	⑪
_		SD card remain	e is connected ing capacity: 4G	•	xxx.jpg	1.1M	1	Û
5		Connect ti	ne device		xxx.mp4	1.1M	1	ŵ
		Play	list					
		Screen br	rightness					
		Timing						
		00						
	_							
	P	laylist						
		Edit: Select the corresponding playback file, click the Edit button, modify the play times.						
	6	2 Add:	Add: Click the add button, you will see the select option			ption.		

select the content you want to display.



3 Up: Select the corresponding play file, click the up button, move the play file



4 Down: Select the corresponding play file, click the down button, move the play file.



5 Delete:Select the content you want to delete in the clip list, and click the delete.



6 Empty: Click the empty button, then you can empty all of the contents in the list

	DSEE.LAB					
	Connect the device Playlist Screen brightness Timing	Screen brightness				
s	Screen brightness					

Connect the device Playlist Screen brightness Timing	Timing start-up ••• 0 0 : 0 0 o Timing shutdown ••• 0 9 : 2 1 : 0 0	
---	---	--

Timing

Enter your time schedule on the timing parts.



Configuration of the Phone APP

Software downloads

1

2

Download the software via http://www.dseelab.com

Wifi connection

Make sure the phone is connect with the device wifi











8	xxxxx.mp4 Cycles: 1 xxxxmp4 Cycles: 4 xxmp4 Cycles: 6 C xxxmp4 Cycles: 6 C C xxxxmp4 Cycles: 10 C C C	File Name: xxxx.mp4 Cycles: Cancel OK				
Setting play times of single file						

Left slide the corresponding file, edit button will appear, click to edit dialog box (Note: 0 for a single file loop)